

## DELL R730/R740 2U server Setup

## **Quick Start Guide**

08/20/2020



## 1 Network Configuration

Before capturing packets, some initial configuration is required.

A VGA display and USB keyboard are necessary at first for locally configuring the network. An Ethernet connection to an onboard gigabit interface is also required.

Note: By default the management Ethernet port is pre-configured for DHCP. If a static IP is needed, you will need to set this during the quick start process.

-				
1.	Provide a network connection for remote access to server	Provide an Ethernet connection to the left most Ethernet port physically shown in the picture wit white cable(blue square).		
2.	Provide a network connection(s) for network capture	Provide 10G optical fiber (850nm, multimode, SF connection(s) using the Interfaces 0 and/or 1 as s the figure(red square). Note: Make sure there is traffic being generated connections.	shown in	
3.	Log in	After booting the system to the OS, login with the following user information: User: <i>continuum</i> Password: <i>Contact Support</i>		
4.	Record the IP Address	Once logged in, open a terminal and enter: #ifco This will provide the IP address of the Ethernet p currently connected. Record the IP address. (Note: to set a static IP address, please review th Continuum User Guide.)	ort UP BROADCAST RUMING MULTICAST MTU:150 Matk:25.25.25.25.8 BROADCAST RUMING MULTICAST MTU:150 Matric:1 BX packets:276 errors:0 dropped:0 overruns:0 frame:0 TX packets:89 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txgueuelen:1000	

support@nextcomputing.com



5. Test connection	To test the connection, ping your internal network or login remotely via SSH on port 22. If there is a successful connection, please go to part 2 of this guide. If not please contact support.		
2 Start		vork and/or cluster connection to the g network packets to disk. Using the ecording and view statistics about	
1. Start the web interface	Remote Access: On any remote system connected to the network, open a web browser (firefox) and enter the IP address of the system followed by the port# 41390 in the form: <a href="https://states-stata390">https://states-stata390</a> Local Access: On the VM, click on the Application tab and select internet. Open a web browser (firefox) and enter   https:// <localhost>:41390</localhost>		
2. Log in:	Now you should see the Packet Continuum login screen. By default, a "continuum" account has already been created. Enter "continuum" for the UserName, and <i>contact support</i> for the Password.		

support@nextcomputing.com